



# Replacement Cartridge for Inline Shower Filter

## Installation

1. By hand, unscrew housing cover from shower filter
2. Remove old cartridge and insert new cartridge
3. Screw housing cover back onto shower filter  
(do not over-tighten)

## Precautions

- Lifespan of shower filter cartridge is dependent on the quality of influent water
- Water filtered by shower filter cartridge is not advised for drinking water purposes
- Do not use when line pressure exceeds 100 psi (6.9 bar)
- Do not exceed 120° F (48.9° C)
- Do not install in direct sunlight
- Protect from freezing

## Parts

- Filter cartridge
- Instructions

## Specifications

- H: 4.2" (105.8mm) x diameter: 2.3" (56.5mm)
- Operating pressure: 20 - 100 psi (1.4 - 6.9 bar)
- Operating temperature range: 40° - 120° F (4° - 48.9° C)
- Optimal pH range: 6.5 - 8.5

## Cartridge Lifespan

Each cartridge lasts up to 30,000 gallons or approximately 1 year with typical use.

## Important Flush Cartridge Before First Use

To prevent stains, flush the cartridge to clear excess carbon. After installing, point shower head toward non-porous shower wall. Turn on water. Run until water runs clear (about 3-5 minutes).